

Spare


Coil Head

Silicone Cover

(to avoid splatter)

Package Includes

Getting Started



Getting Started





4. Twist the base back to the I closed position. DASOX is ready I for use!

Power Indicator

The light on the device changes color during use to indicate the remaining battery life as follows:



Green - the device has 80%-100% battery life.

Power

Blue - the device has 20%-79% battery life.

20% - 79% Power

0% -19% Power

Red - the device has 0%-19% battery life.



 \vee i \vee \triangle N \top [™]



For additional information and instructions, please visit us at www.vivant.com

Web: www.vivant.com

Charging

Note:

Connect the device to a wall

adapter via the provided USB

cable. We recommend a 2 amps

The device is fully charged

when the red light is off.

charging adapter.

Please disconnect the device from the

charger once charging is complete.

Coil Replacement

Twist open the base to the

second position (90 degrees)

ENSURE THAT THE DEVICE IS OFF AND

THE COIL HEAD HAS COOLED BEFORE

REPLACEMENT OR ADJUSTMENT! MAY

CAUSE BURNS OR SERIOUS INJURY IF

2. Grip the coil head on the

sides and pull it straight out

to remove the coil assembly

from the base.

to access the coil

HANDLED WHILE HOT

Coil Replacement



3. Twist the coil head counter clockwise to remove the coil from the adapter.



4.Replace the coil head by twisting your new coil head



5. Slide the coil assembly along the tracks back into the



clockwise onto the adapter.

Authentic Vivant product replacement This warranty provides free replacement if authentic

 VIVANT product cannot work due to manufacturer defects, in the precondition of non-artificial damage. Warranty period is 2 years from date of purchase by the end user with proof of receipt.

Void of warranty

Warranty

This warranty will be void as a result of any of the following conditions:

Customer is unable to provide original receipt of purchase.

Product failure or damage caused due to improper use or unauthorized repair and alteration.

Product failure or damage caused due to use of excessive force or negligence such as dropping the device

Product failure or damage caused due to usage with non-VIVANT components such as power

Non-Vivant brand prodcuts

This warranty does not cover any non-VVANT brand products.

This warranty is only valid for authentic VIVANT products within 2 years after date of purchase by the end user.

VIVANT INC.

3059 Edinger Ave. Tustin, CA 92780 USA

E-mail: info@vivant.com

Tel: +1 844-8-VIVANT (+1 844-884-8268)